

SECTION **IDX**
ALPHABETICAL INDEX

A
B
C
D
E
F
G
H
I
J
K
L

IDX

ALPHABETICAL INDEX

Numerics	
3METER - Wiring diagram	DI-34
A	
A/C component layout	ATC-23
A/C compressor clutch removal and installation	ATC-135
A/C compressor mounting	ATC-134
A/C compressor precaution	ATC-11
A/C compressor special service tool	ATC-15
A/C controller	ATC-110
A/C diagnostic work flow (auto A/C)	ATC-99
A/C evaporator	ATC-146
A/C HFC134a (R134a) system precaution	ATC-5
A/C HFC134a (R134a) system service procedure	ATC-131
A/C HFC134a (R134a) system service tools ...	ATC-15
A/C HFC134a system service equipment precaution ...	ATC-12
A/C lubricant (R134a)	ATC-24
A/C lubrication oil	ATC-152
A/C operational check	ATC-63
A/C self-diagnoses (auto A/C)	ATC-55 , ATC-99
A/C service data specification	ATC-152
A/C trouble diagnoses (auto A/C)	ATC-42
A/C, A - Wiring diagram	ATC-48
A/T - Wiring diagram	AT-48
A/T fluid checking	AT-11 , AT-54
A/T fluid replacement	AT-11
A/T fluid temperature sensor	AT-110
A/T IND - Wiring diagram	DI-77
A/T self-diagnoses	AT-74 , AT-84
A/T shift lock system	AT-179
A/T shift lock system - Wiring diagram	AT-180
A/T trouble diagnoses	AT-39
ABS - Wiring diagram	BRC-16
ABS input/output signal inspection	BRC-20
Accelerator control system	ACC-2
Accelerator pedal position (APP) sensor	EC-544 , EC-550 , EC-562
Accelerator pedal released position learning	EC-50
Air bag	SRS-3
Air bag disposal	SRS-50
Air bag precautions	SRS-3
Air bleeding (hydraulic clutch)	CL-8
Air bleeding for brake system	BR-10
Air cleaner and air duct	EM-15
Air cleaner filter replacement	MA-17
Air conditioner cut control	EC-28
Air flow meter - See Mass air flow sensor	EC-168 , EC-176
Air mix. door motor	ATC-72 , ATC-126
Air spoiler, rear	EI-26
Ambient sensor	ATC-100 , ATC-112
Angular tightening application	EM-4
Antenna	AV-30
APPS1 - Wiring diagram	EC-546
APPS2 - Wiring diagram	EC-552
APPS3 - Wiring diagram	EC-564
ASC/BS - Wiring diagram	EC-513
ASC/SW - Wiring diagram	EC-506
ASCBOF - Wiring diagram	EC-601
ASCD	EC-635
ASCD (automatic speed control device)	ACS-2
ASCIND - Wiring diagram	EC-617
Ashtray illumination	LT-204
AT indicator lamp	DI-77
Audio	AV-5
AUDIO - Wiring diagram	AV-8
Auto air conditioner - Wiring diagram	ATC-48
Auto amp	ATC-111
Auto anti-dazzling inside mirror	GW-55
Automatic amplifier	ATC-65 , ATC-111
Automatic transmission fluid replacement	MA-23
Axle	MA-29
Axle housing (rear)	RAX-8
B	
Back Door	BL-84 , BL-85
Back door	BL-84 , BL-85
Back door opener - See Back door	BL-89
BACK/L - Wiring diagram	LT-173
Back-up lamp	LT-173
Back-up lamp switch (M/T)	MT-9
Battery	SC-4
Battery/Starting/Charging System Tester	SC-6 , SC-14 , SC-22
BCM (Body control module)	BCS-3
Blower motor	ATC-79 , ATC-119
Blower unit	ATC-117
Bose speaker amp.	AV-5
Brake booster	BR-22
Brake fluid change	BR-9
Brake fluid level	MA-27
Brake fluid level and line check	BR-9
Brake hydraulic line	BR-11
Brake inspection	MA-27
Brake lines and cables inspection	MA-27
Brake master cylinder	BR-14
Brake pedal	BR-6
Brake switch	EC-538
BRK/SW - Wiring diagram	EC-539
Bulb specifications	LT-237
Bumper, front	EI-14
Bumper, rear	EI-17
C	
Camshaft	EM-64
Camshaft inspection	EM-66
Camshaft position sensor (PHASE)	EC-308
CAN	WT-11
CAN - Wiring diagram	EC-147 , LAN-15 , LAN-39 , LAN-58 , LAN-81 , LAN-100 , LAN-123 , LAN-145
CAN (Controller Area Network)	LAN-6 , LAN-14 ,

ALPHABETICAL INDEX

[LAN-38](#), [LAN-57](#), [LAN-80](#), [LAN-99](#), [LAN-122](#), [LAN-144](#)
 CAN communication ... [EC-30](#), [EC-146](#), [AT-26](#), [AT-86](#),
[BRC-8](#), [BRC-50](#), [BRC-98](#), [LT-9](#), [LT-37](#), [LT-135](#), [LT-177](#),
[LT-221](#), [WW-9](#), [LAN-6](#), [LAN-14](#), [LAN-38](#), [LAN-57](#),
[LAN-80](#), [LAN-99](#), [LAN-122](#), [LAN-144](#)
 Canister-See EVAP canister [EC-624](#)
 CHARGE - Wiring diagram [SC-21](#)
 Charging system [SC-20](#)
 Chassis and body maintenance [MA-21](#)
 CHIME - Wiring diagram [DI-91](#)
 Circuit breaker [PG-16](#)
 Clock [DI-106](#)
 CLOCK - Wiring diagram [DI-106](#)
 Closed loop control [EC-26](#)
 Clutch cover [CL-16](#)
 Clutch disc [CL-16](#)
 Clutch master cylinder [CL-9](#)
 Clutch operating cylinder [CL-12](#)
 Clutch pedal [CL-5](#)
 Clutch release bearing [CL-14](#)
 Clutch release mechanism [CL-14](#)
 Clutch withdrawal lever [CL-14](#)
 Coil spring (front) [FSU-10](#)
 Collision diagnosis [SRS-57](#)
 Combination lamp, front, removal and installation
[LT-61](#), [LT-130](#)
 Combination lamp, rear, removal and installation
[LT-199](#)
 Combination meter [DI-4](#)
 Combination meter removal and installation - See
 Instrument panel [IP-12](#)
 Combination switch [LT-158](#)
 Component Location (auto A/C) [ATC-45](#)
 Compression pressure [EM-78](#)
 Compressor clutch removal and installation .. [ATC-135](#)
 Compressor special service tool [ATC-15](#)
 Condenser [ATC-144](#)
 Console box - See Instrument panel [IP-11](#)
 CONSULT for ABS [BRC-21](#)
 CONSULT for TCS [BRC-65](#)
 CONSUT for VDC [BRC-116](#)
 Control units (terminal arrangement) [PG-71](#)
 Control valve (A/T) [AT-33](#)
 Controller Area Network (CAN) [LAN-6](#), [LAN-14](#),
[LAN-38](#), [LAN-57](#), [LAN-80](#), [LAN-99](#), [LAN-122](#), [LAN-144](#)
 Converter housing installation [AT-189](#)
 COOL/F - Wiring diagram [EC-472](#)
 Cooling circuit (engine) [CO-7](#)
 Cooling fan motor [EC-480](#)
 Cowl top [EI-20](#)
 Cowl top cover [EI-20](#)
 Crankcase ventilation system - See Positive crankcase
 ventilation [EC-633](#)
 Crankshaft position sensor (POS) [EC-302](#)
 Crash zone sensor [SRS-46](#)
 Cylinder head [EM-78](#)

D

D/LOCK - Wiring diagram [BL-22](#)
 Daytime light system [LT-64](#), [LT-100](#)
 Daytime running light - See Daytime light system
[LT-64](#), [LT-100](#)
 DEF - Wiring diagram [GW-68](#)
 Diagnosis sensor unit [SRS-49](#)
 Diagnostic trouble code (DTC) for OBD system .. [EC-8](#)
 Diagnostic trouble code (DTC) inspection priority chart
[AT-39](#)
 Differential carrier assembly [RFD-12](#)
 Differential carrier disassembly [RFD-16](#)
 Differential gear oil replacement [MA-25](#)
 Direct clutch solenoid valve [AT-129](#), [AT-131](#)
 Display and amp.assembly [ATC-65](#)
 Door glass [GW-52](#)
 Door glass Fitting Adjustment(Front) [GW-54](#)
 Door lock [BL-82](#)
 Door mirror [GW-85](#)
 Door trim [EI-28](#)
 Door, front [BL-79](#), [GW-52](#)
 Drive belt [EM-13](#)
 Drive belt inspection [MA-13](#)
 Drive pinion diff. inspection [RFD-15](#)
 Drive pinion height [RFD-21](#), [RFD-24](#)
 Drive shaft [MA-30](#)
 Drive shaft (rear) [RAX-10](#)
 Driver air bag [SRS-38](#)
 DTRL - Wiring diagram [LT-76](#), [LT-111](#)
 Duct and grilles [ATC-127](#)

E

ECM power supply [EC-138](#), [EC-401](#)
 ECM/PW - Wiring diagram [EC-402](#)
 ECTS - Wiring diagram [EC-190](#)
 Electric throttle control actuator [EC-412](#), [EC-414](#)
 Electrical load signal circuit [EC-599](#)
 Electrical unit [PG-71](#)
 Electrical units location [PG-63](#)
 Electronic ignition (EI) system [EC-27](#)
 Engine control module (ECM) [EC-398](#)
 Engine control system diagram and chart [EC-22](#)
 Engine coolant [CO-8](#)
 Engine coolant temperature sensor (ECTS) ... [EC-188](#),
[EC-199](#)
 Engine oil [LU-6](#)
 Engine oil filter replacement [MA-18](#)
 Engine oil precautions [GI-7](#)
 Engine removal [EM-89](#)
 ETC1 - Wiring diagram [EC-415](#)
 ETC2 - Wiring diagram [EC-422](#)
 ETC3 - Wiring diagram [EC-426](#)
 EVAP canister [EC-624](#)
 EVAP canister purge volume control solenoid valve
[EC-335](#), [EC-489](#)
 EVAP canister vent control valve [EC-342](#), [EC-497](#)
 EVAP control system (small leak) diagnosis .. [EC-326](#),

ALPHABETICAL INDEX

[EC-363](#)

EVAP control system pressure sensor [EC-349](#), [EC-355](#)

EVAP control system purge flow monitoring diagnosis

[EC-321](#)

EVAP vapor lines inspection [MA-20](#)

Evaporative emission (EVAP) system [EC-621](#)

Evaporator [ATC-146](#)

Exhaust manifold [EM-23](#)

Exhaust system [EX-3](#)

Exhaust system inspection [EX-3](#), [MA-21](#)

Expansion valve [ATC-147](#)

F

F/LID - Wiring diagram [BL-47](#)

F/PUMP - Wiring diagram [EC-588](#)

Final drive disassembly [RFD-16](#)

Final drive pre-inspection [RFD-15](#)

Final drive removal and installation [RFD-10](#)

Floor trim [EI-34](#)

Flow charts [GI-27](#)

Fluid temperature sensor (A/T) [AT-110](#)

Fluorescent leak detector [ATC-148](#)

Flywheel (clutch) [CL-16](#)

Flywheel runout(QR) [EM-117](#)

Front axle [FAX-4](#)

Front brake solenoid valve [AT-125](#), [AT-127](#)

Front bumper [EI-14](#)

Front combination lamp removal and installation [LT-61](#),

[LT-130](#)

Front door [BL-79](#), [GW-52](#)

Front passenger air bag [SRS-42](#)

Front seat belt [SB-4](#)

Front seat belt pre-tensioner [SB-2](#), [SRS-3](#), [SRS-48](#)

Front side air bag [SRS-43](#)

Front suspension [FSU-5](#)

Front washer [WW-4](#)

Front wiper [WW-4](#)

FTTS - Wiring diagram [EC-278](#), [EC-282](#)

Fuel cut control (at no load high engine speed) . [EC-28](#)

Fuel filter replacement [FL-5](#)

Fuel gauge [DI-4](#)

Fuel level sensor [EC-381](#), [EC-383](#), [EC-385](#)

Fuel lid opener, electric [BL-47](#)

Fuel line inspection [FL-3](#), [MA-17](#)

Fuel precautions [GI-6](#)

Fuel pressure check [EC-53](#)

Fuel pressure release [EC-53](#)

Fuel pump [EC-587](#)

Fuel pump and gauge [FL-5](#)

Fuel system [FL-3](#)

Fuel tank [FL-11](#)

Fuel tank temperature sensor [EC-276](#), [EC-281](#)

Fuel tank vacuum relief valve [EC-624](#)

FUELB1 - Wiring diagram [EC-261](#), [EC-270](#)

FUELB2 - Wiring diagram [EC-262](#), [EC-271](#)

Fuse [PG-16](#)

Fuse and fusible link box [PG-78](#)

Fusible link [PG-16](#)

G

Gauges [DI-4](#)

Glass [GW-11](#), [GW-52](#)

GPS antenna [AV-35](#)

Ground distribution [PG-31](#)

H

H/LAMP - Wiring diagram [LT-17](#), [LT-46](#)

Harness connector [PG-68](#)

Harness layout [PG-43](#)

Hazard warning lamp [LT-133](#)

Headlamp [LT-7](#), [LT-36](#)

Headlamp removal and installation [LT-61](#), [LT-130](#)

Headlining - See Roof trim [EI-35](#)

Heated oxygen sensor 1 (bank 1) [EC-207](#), [EC-216](#),

[EC-229](#), [EC-430](#), [EC-436](#)

Heated oxygen sensor 1 (bank 2) [EC-207](#), [EC-216](#),

[EC-229](#), [EC-430](#), [EC-436](#)

Heated oxygen sensor 1 heater (bank 1) [EC-152](#)

Heated oxygen sensor 1 heater (bank 2) [EC-152](#)

Heated oxygen sensor 2 (bank 1) [EC-239](#), [EC-248](#),

[EC-442](#), [EC-453](#)

Heated oxygen sensor 2 (bank 2) [EC-239](#), [EC-248](#),

[EC-442](#), [EC-453](#)

Heated oxygen sensor 2 heater (bank 1) [EC-160](#)

Heated oxygen sensor 2 heater (bank 2) [EC-160](#)

Heated seat [SE-13](#)

Heater and cooling unit (Heater core) [ATC-121](#)

HFC134a (R134a) system precaution [ATC-5](#)

HFC134a (R134a) system service procedure [ATC-131](#)

HFC134a (R134a) system service tools [ATC-15](#)

HFC134a system service equipment precaution

[ATC-12](#)

High & low reverse clutch solenoid valve [AT-133](#),

[AT-135](#)

Hood [BL-12](#)

Hood lock system [BL-14](#)

Horn [WW-55](#)

HORN - Wiring diagram [WW-55](#)

HSEAT - Wiring diagram [SE-15](#)

I

IATS - Wiring diagram [EC-185](#)

Idle air volume learning [EC-51](#)

Idle mixture ratio [EC-40](#)

Idle speed [EC-40](#)

Idle speed control (ISC) [EC-389](#), [EC-391](#)

Ignition coil [EM-30](#), [EC-569](#)

Ignition control system [EC-569](#)

Ignition timing [EC-40](#)

IGNSYS - Wiring diagram [EC-570](#)

ILL - Wiring diagram [LT-229](#)

Illumination [LT-220](#)

In vehicle sensor [ATC-102](#), [ATC-113](#)

INJECT - Wiring diagram [EC-582](#)

Injector [EC-581](#)

ALPHABETICAL INDEX

Input clutch solenoid valve [AT-121](#), [AT-123](#)
Instrument panel [IP-11](#)
INT/L - Wiring diagram [LT-201](#)
Intake air temperature sensor [EC-183](#), [EC-202](#)
Intake door control linkage adjustment [ATC-78](#)
Intake door motor [ATC-76](#), [ATC-120](#)
Intake manifold [EM-21](#)
Intake manifold collector [EM-17](#)
Intake sensor [ATC-108](#), [ATC-115](#)
Intake valve timing control (Bank 1) [EC-149](#)
Intake valve timing control (Bank 2) [EC-149](#)
Intake valve timing control solenoid valve (Bank 1)
[EC-405](#)
Intake valve timing control solenoid valve (Bank 2)
[EC-405](#)
Integrated homelink transmitter [BL-139](#)
Interior [EI-30](#)
Interior lamp [LT-205](#)
IPDM (Intelligent power distribution module engine
room) [PG-17](#)
IVCB1 - Wiring diagram [EC-406](#)
IVCB2 - Wiring diagram [EC-408](#)
IVIS (Infiniti vehicle immobilizer system) precautions ...
[GI-3](#)

J

Joint connector (J/C) [PG-70](#)

K

KEYLES - Wiring diagram [BL-59](#)
Knock sensor (KS) [EC-297](#)
KS - Wiring diagram [EC-298](#)

L

LAN system circuit [ATC-67](#)
License lamp [LT-176](#)
Line pressure solenoid valve [AT-101](#)
Line pressure test (A/T) [AT-56](#)
Liquid gasket application [LU-2](#), [CO-2](#)
Location of electrical units [PG-63](#)
Lock, door [BL-82](#)
Low coast brake solenoid valve [AT-137](#), [AT-139](#)
Low tire pressure warning system [WT-9](#)
Lubricant (R134a) A/C [ATC-6](#), [ATC-24](#)
Lubrication circuit (engine) [LU-4](#)
Lubrication oil A/C [ATC-152](#)
Luggage room lamp [LT-201](#)

M

M/ANT - Wiring diagram [AV-31](#)
M/T oil replacement [MT-7](#)
M/T removal and installation [MT-15](#)
MAFS - Wiring diagram [EC-171](#), [EC-178](#)
Magnet clutch [ATC-84](#), [ATC-135](#)
MAIN - Wiring diagram [EC-138](#)

Maintenance (engine) [MA-13](#)
Manual transmission oil replacement ... [MA-21](#), [MA-22](#)
Mass air flow sensor (MAFS) [EC-168](#), [EC-176](#)
Master cylinder (clutch) [CL-9](#)
Meter [DI-4](#)
METER - Wiring diagram [DI-9](#)
MIL data link connectors circuit [EC-619](#)
MIL/DL - Wiring diagram [EC-619](#)
MIRROR - Wiring diagram [GW-84](#)
Mirror, door [GW-85](#)
Mirror, out side [GW-85](#)
Misfire [EC-291](#)
Mode door control linkage adjustment [ATC-72](#)
Mode door motor [ATC-70](#), [ATC-125](#)
Molding - See Exterior [EI-22](#), [EI-24](#)
Multiport fuel injection (MFI) system [EC-25](#)
Multiport fuel injection precautions [GI-6](#)

N

NATS - Wiring diagram [BL-123](#)
NAVI - Wiring diagram [AV-49](#)
Navigation system [AV-34](#)
NVH troubleshooting (BR) [BR-5](#)
NVH troubleshooting (CL) [CL-4](#)
NVH troubleshooting (EM) [EM-11](#)
NVH troubleshooting (FAX) [FAX-3](#)
NVH troubleshooting (FSU) [FSU-4](#)
NVH troubleshooting (M/T) [MT-4](#)
NVH troubleshooting (PR) [PR-4](#)
NVH troubleshooting (RAX) [RAX-5](#)
NVH troubleshooting (RFD) [RFD-5](#)
NVH troubleshooting (RSU) [RSU-4](#)
NVH troubleshooting (ST) [PS-5](#)
NVH troubleshooting (WT) [WT-5](#)
NVIS (Nissan vehicle immobilizer system) [BL-120](#)
NVIS (Nissan vehicle immobilizer system) precautions
[GI-3](#)

O

O2H1B1 - Wiring diagram [EC-154](#)
O2H1B2 - Wiring diagram [EC-156](#)
O2H2B1 - Wiring diagram [EC-162](#)
O2H2B2 - Wiring diagram [EC-164](#)
O2S1B1 - Wiring diagram ... [EC-209](#), [EC-219](#), [EC-232](#)
O2S1B2 - Wiring diagram ... [EC-211](#), [EC-221](#), [EC-234](#)
O2S2B1 - Wiring diagram .. [EC-241](#), [EC-251](#), [EC-445](#),
[EC-456](#)
O2S2B2 - Wiring diagram .. [EC-243](#), [EC-253](#), [EC-447](#),
[EC-458](#)
Oil cooler (engine) [LU-10](#)
Oil filter [LU-9](#)
Oil pan (engine) [EM-26](#)
Oil pressure (engine) [LU-7](#)
Oil pump (engine) [LU-12](#)
Oil pump regulator valve (engine) [LU-12](#)
Oil seal replacement (front of final drive) [RFD-6](#)
Oil seal replacement (side of final drive) [RFD-8](#)

ALPHABETICAL INDEX

Operating cylinder (clutch) [CL-12](#)
 ORVR (On-board Refueling Vapor Recovery) . [EC-628](#)
 Out side mirror [GW-85](#)
 Overheat [EC-468](#)

P

P/SCKT - Wiring diagram [WW-53](#)
 Park/Neutral position switch [EC-530](#)
 Park/neutral position switch (A/T) [AT-91](#)
 Parking brake control [PB-4](#)
 Parking lamp [LT-176](#)
 PCV (positive crankcase ventilation) [EC-633](#)
 PGC/V - Wiring diagram [EC-337](#), [EC-491](#)
 PHSB1 - Wiring diagram [EC-309](#)
 PHSB2 - Wiring diagram [EC-311](#)
 Pinion bearing preload diff. [RFD-30](#)
 Pinion gear height diff. [RFD-24](#)
 PNP/SW - Wiring diagram [EC-532](#)
 POS - Wiring diagram [EC-303](#)
 POWER - Wiring diagram [PG-5](#)
 Power door lock [BL-18](#)
 Power seat [SE-11](#)
 Power socket [WW-53](#)
 Power steering fluid level [PS-6](#), [MA-29](#)
 Power steering gear [PS-17](#)
 Power steering hydraulic pressure [PS-29](#)
 Power steering oil pump [PS-29](#)
 Power steering system bleeding [PS-6](#)
 Power supply routing [PG-4](#)
 Power window [GW-17](#)
 PRE/SE - Wiring diagram [EC-351](#), [EC-357](#)
 Precations for Leak detection dye [ATC-14](#)
 Precautions (General) [GI-4](#)
 Pressure plate - See Clutch cover [CL-16](#)
 Pressure switch 1 [AT-127](#), [AT-144](#)
 Pressure switch 2 [AT-139](#)
 Pressure switch 3 [AT-123](#), [AT-146](#)
 Pressure switch 5 [AT-131](#), [AT-148](#)
 Pressure switch 6 [AT-135](#), [AT-150](#)
 Pressure test (A/T) [AT-56](#)
 Propeller shaft [PR-5](#)
 Propeller shaft inspection [MA-24](#)
 Propeller shaft on vehicle service [PR-5](#)
 Propeller shaft vibration [PR-5](#)
 PS/SEN - Wiring diagram [EC-394](#)

R

Radiator [CO-11](#)
 Radio - See Audio [AV-5](#)
 Rear axle [RAX-6](#)
 Rear bumper [EI-17](#)
 Rear combination lamp removal and installation
[LT-199](#)
 Rear cover packing replacement diff. [RFD-31](#)
 Rear suspension [RSU-5](#)
 Rear washer [WW-38](#)
 Rear window defogger [GW-58](#)

Rear wiper [WW-38](#)
 Refrigerant connection precaution [ATC-6](#)
 Refrigerant discharging evacuating charging [ATC-131](#)
 Refrigerant general precaution [ATC-6](#)
 Refrigerant lines [ATC-131](#)
 Refrigerant pressure sensor [EC-594](#), [ATC-89](#),
[ATC-146](#)
 Refrigeration cycle [ATC-19](#)
 Release bearing (clutch) [CL-14](#)
 Remote keyless entry system [BL-48](#)
 Removal and installation (A/T) [AT-188](#)
 Reverse lamp switch (M/T) - See Back-up lamp switch
 (M/T) [MT-9](#)
 Revolution sensor (A/T) [AT-93](#)
 Ring gear diff. inspection [RFD-15](#)
 Rocker cover [EM-38](#)
 Room lamp - See Interior lamp [LT-205](#)
 ROOM/L - Wiring diagram [LT-209](#)
 RP/SEN - Wiring diagram [EC-595](#)

S

SEAT - Wiring diagram [SE-11](#)
 Seat belt inspection [SB-6](#)
 Seat belt pre-tensioner disposal [SRS-50](#)
 Seat belt, front [SB-4](#)
 SEN/PW - Wiring diagram [EC-486](#)
 SHIFT - Wiring diagram [AT-180](#)
 Shift lock system [AT-179](#)
 Shift schedule [AT-191](#)
 Shock absorber (front) [FSU-10](#)
 Shock absorber (rear) [RSU-9](#)
 Side air bag (satellite) sensor [SRS-47](#)
 Side bearing preload diff. [RFD-23](#)
 Side curtain air bag [SRS-44](#)
 Side flange installation diff. [RFD-9](#)
 Side trim [EI-30](#)
 SMJ (super multiple junction) [PG-73](#)
 Spark plug [EM-31](#)
 Spark plug replacement [MA-19](#)
 Specification value [EC-133](#)
 Speedometer [DI-4](#)
 Spiral cable [SRS-40](#)
 SRS - See Supplemental Restraint System [SRS-7](#)
 SRS - Wiring diagram [SRS-13](#)
 SRS Trouble diagnoses [SRS-9](#)
 Stabilizer bar (rear) [RSU-16](#)
 Stall test (A/T) [AT-54](#)
 Standardized relay [PG-75](#)
 START - Wiring diagram [SC-11](#)
 Starter [SC-10](#)
 Starting system [SC-10](#)
 Steering gear and linkage inspection [MA-28](#)
 Steering linkage [PS-17](#)
 Steering wheel and column [PS-7](#), [PS-9](#)
 Steering wheel turning force [PS-8](#)
 Stop lamp [LT-170](#)
 Stop lamp switch [EC-538](#)
 STOP/L - Wiring diagram [LT-170](#)

ALPHABETICAL INDEX

Sunload sensor [ATC-105](#), [ATC-114](#)
 Supplemental Restraint System [SRS-7](#)
 Supplemental restraint system - Wiring diagram
[SRS-13](#)
 Suspension [MA-29](#)
 Symbols and abbreviations [GI-10](#), [GI-23](#)

T

Tachometer [DI-4](#)
 Tail lamp [LT-176](#)
 TAIL/L - Wiring diagram [LT-186](#)
 TCM circuit diagram [AT-47](#)
 TCM inspection table [AT-73](#)
 TCS - Wiring diagram [BRC-59](#)
 Thermostat [CO-23](#)
 Three way catalyst [EM-23](#)
 Three way catalyst function (Bank 1) [EC-316](#)
 Three way catalyst function (Bank 2) [EC-316](#)
 Three way catalyst precautions [GI-5](#)
 Throttle body [EM-20](#)
 Throttle control motor [EC-425](#)
 Throttle control motor relay [EC-420](#)
 Throttle position sensor (TPS) [EC-193](#), [EC-285](#),
[EC-481](#), [EC-483](#), [EC-556](#)
 Throwout bearing - See Clutch release bearing [CL-14](#)
 Thrust washer selection diff. [RFD-22](#)
 Tie-rod [PS-17](#)
 Timing chain [EM-48](#)
 Tire rotation [WT-8](#), [MA-26](#)
 Tooth contact diff. [RFD-27](#)
 Torque converter installation [AT-189](#)
 Torque convertor clutch solenoid valve .. [AT-97](#), [AT-99](#)
 TPS1 - Wiring diagram [EC-287](#)
 TPS2 - Wiring diagram [EC-195](#)
 TPS3 - Wiring diagram [EC-558](#)
 Transverse link (front) [FSU-13](#)
 Triple meter [DI-29](#)
 TRNSCV - Wiring diagram [BL-139](#)
 Trouble diagnoses [GI-11](#)
 Turbine revolution sensor [AT-112](#)
 Turbocharger precautions [GI-6](#)
 TURN - Wiring diagram [LT-144](#)
 Turn signal lamp [LT-133](#)
 Tyre pressure monitoring system - trouble diagnoses ..
[WT-19](#)
 Tyre pressure monitoring system - wiring diagram
[WT-20](#)

U

Unified meter and A/C amp. [DI-50](#)
 Upper link (front susp.) [FSU-14](#)

V

Vacuum hose (brake system) [BR-24](#)
 Vacuum hose drawing (Engine control) [EC-23](#)
 Valve clearance [EM-71](#)

Valve guide [EM-83](#)
 Valve lifter [EM-68](#)
 Valve seat [EM-85](#)
 Valve spring [EM-87](#)
 Vanity mirror lamp [LT-200](#)
 VDC -Wiring diagram [BRC-106](#)
 VEHICLE SECURITY (THEFT WARNING) SYSTEM ..
[BL-90](#)
 Vehicle speed sensor (VSS) [EC-387](#)
 VENT/V - Wiring diagram [EC-344](#), [EC-499](#)

W

WARN - Wiring diagram [DI-67](#)
 Warning chime [DI-81](#)
 Warning lamps [DI-66](#)
 Washer, front [WW-4](#)
 Washer, rear [WW-38](#)
 Water pump [CO-19](#)
 Water temperature gauge [DI-4](#)
 Wheel alignment (front) [FSU-5](#)
 Wheel alignment (rear) [RSU-5](#)
 Wheel balance [WT-7](#), [MA-25](#)
 Wheel bearing (front) [FAX-4](#)
 Wheel bearing (rear) [RAX-6](#)
 Wheel hub (front) [FAX-4](#)
 Wheel hub (rear) [RAX-6](#)
 Wheel sensor(VDC) [BRC-149](#)
 Wheel sensors (ABS) [BRC-41](#)
 Wheel sensors (TCS) [BRC-87](#)
 WINDOW - Wiring diagram [GW-22](#)
 Window, door [GW-52](#)
 Windshield [GW-11](#)
 WIP/R - Wiring diagram [WW-40](#)
 WIPER - Wiring diagram [WW-18](#)
 Wiper, front [WW-4](#)
 Wiper, rear [WW-38](#)
 Wiring Diagram - VEHSEC - [BL-101](#)
 Wiring Diagram (Cell code) list [PG-60](#)
 Wiring diagrams [GI-15](#)
 Withdrawal lever (clutch) [CL-14](#)
 WT-T/WARN - Wiring diagram [WT-20](#)

A
B
C
D
E
F
G
H
I
J
K
L

IDX