



## **Installation Instructions Addendum**

**Part number 1095XX, 1097XX Frameless Soft Top  
for Jeep® Wrangler TJ 1997-2006  
and 1096XX for Jeep® Wrangler LJ Unlimited 2004-2006**

**NOTE: Installation of the top in warm weather is optimal for ease of installation. Ideal installation temperature should not be less than 70° (21C). Initial installation is the most difficult as the fabric has not been stretched. The top will loosen slightly with use and warm temperature. Allow about at least an hour for the initial installation.**

**\*\*\*Please follow instructions for ease of installation and correct fit.\*\*\***

The Frameless Trail Top is an innovative top designed to be the only top a person will ever need. Due to it's design however, installation can be tricky at times. New fabric, fresh seams and cold weather all play a part in the top's installation.

Occasionally during install as per the instructions, it could appear that the back window is not cut in the right shape and/or you are unable to connect both side zippers. The back window is designed to have a taper of approximately 3" top to bottom. The back window may appear to not be built correctly, but is in fact correct for the vehicle. Reference Figure A for a visual of what the issue that you might run into.



- When installing the top, make sure the material is warm to the touch
- Get the main skin installed per the instructions.
- Put in your side panel, get the main skin/side panel zipper started about 6 inches.
- Fit the plastic strip into the door surround - But do not install the plastic strip into the body yet.
- Repeat on the opposite side.
- Put back window into place, hooking up the three straps across the top.
- Hook up the back window/side window zipper, run it down 6" or so.
- Hook up zipper on opposite side of back window, run it down about 6".
- Not having the plastic seal in the body will give you more movement to hook up the back window zippers.
- Install the plastic strip into the body on both sides.
- Run all 4 zippers to their ends alternating between each side to ensure the window is pulled evenly.
- Complete the rest of your installation as per the instructions provided in your kit.

After being installed for a while and the top goes through some heat cycles, the fabric and seams will take a set to being installed and the installation will get easier.