

# NEUSPEED®

## SHORT SHIFT KIT

### PART NUMBERS and APPLICATIONS:

66.02.65: 2006-2006.5 Audi A3 (8P) equipped with both 6-speed transmission and OEM shifter part #1K0 711 051 J

66.02.87: 2002-2006 Audi TT Quattro equipped with 5-speed or 6-speed transmission

66.10.91: 2002-2005 VW Beetle, Golf IV, Jetta IV and R32 equipped with 6-speed transmission

66.10.93: 2005-2006.5 VW GTI MKV, Jetta V and Passat (B6) equipped with both 6-speed transmission and OEM shifter part # 1K0 711 051 J



PART LIST: 1 - GEAR SELECTOR LEVER w/LARGE PIN STUD (.390" / 9.8mm diameter)

TOOLS REQUIRED: 1 - 13mm SOCKET 1 - RATCHET HANDLE  
1 - 6" OR LONGER EXTENSION 1 - TORQUE WRENCH

1. Remove clip on end of shifter cable and remove cable that attaches to gear selector lever.
2. Unbolt gear selector lever from selector shaft using a 13mm socket – remove lever.
3. Grease guide rail on *NEUSPEED*® gear selector lever. Install selector lever by first installing guide rail in white plastic guide. Then match up splines on selector shaft – **note wide alignment spline**. Install lock nut and torque to 20 ft./lbs.
4. Grease pin on gear selector lever and re-attach cable. Re-attach retaining clip.
5. Carefully double-check complete installation to be sure nothing interferes with the shift linkage, tightness of all nuts and bolts, and check that **ALL** gears engage smoothly and fully **BEFORE STARTING ENGINE OR TEST DRIVING!**

©Copyright 2006, *NEUSPEED*®. All rights reserved. Reproduction in whole or in part prohibited.  
DOC.66.10.99 Rev. 05.16.06