



Installation Instructions

Ford F150 Trucks-All Models 2004-2010 Part No. 14420

Parts List:

**8 Main Brackets
8 C Channel Top Clamps
8 Carriage Bolts w/square Flanges
16 5/16" Hex Head Bolts
16 5/16" Flat Washers
24 5/16" Hex Nuts
24 5/16" Lock Washers**

Installation:

1. Locate pre-drilled holes along pinch weld/lower rocker panel of the vehicle. Align and mount main brackets through pre-drilled holes on the pinch weld using 5/16" bolts and flat washers. Secure with lock washer and 5/16" nuts. Hand tighten.
2. Insert 5/16" bolt through flat washer and insert into square hole next to vertical part of main bracket. Pull bolt through pre-drilled smaller hole next to large square hole and through one of the holes on the vertical portion of the main bracket. Note: Vertical area of the bracket is the shorter leg with three holes. Secure with lock washer and 5/16" nuts. Hand tighten.
3. Place board on brackets and secure with C-Channel Clamps and carriage bolts. Place carriage bolts through square hole in C-Channel and align with center hole on bracket. The alignment tab on the C-Channel should fall into a slot-not the center hole. Align C-Channel so that it does not extend beyond the outside edge of the main bracket. Secure using 5/16" nut and lock washer.
4. Set all final positions for height, depth and center. Tighten all nuts, bolts and hardware to secure. Installation is complete.

To Assemble Running Boards:

1. Place large portion of black end cap onto running board by aligning two molded posts into pre-drilled holes on running board ends. Secure by inserting small machine screw into pre-drilled hole along back of running board that will line up with small hole on long end of end cap. Place smaller end cap piece over mounted end cap piece and align posts. Secure using remaining self-tapping screws. Be sure that outside seam is aligned before tightening. We suggest a rotating tightening pattern (like tire tightening) to ensure proper seam alignment. Optional: you may install galvanized flange nuts onto alignment posts if desired but they are not necessary for safe and proper use of running boards.

**Rampage Products 9225 Stellar Ct. Ste "C", Corona , CA 92883
Phone: (951) 277-4949 Fax: (951) 277-2295
www.rampageproducts.net
*Made in China***