

Installation Instructions For 15696

2001- FORD EXPLORER SPORT TRAC - 6CYL 4.0L

Warning: When working on under or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure safe work area. Serious injury or death could occur if safety measures are not followed.



"STABILIZER LINK-TO-FRAME" BOLT TORQUE SHOULD BE 44 - 59ft-lbs.

"STABILIZER-TO-LINK" NUT TORQUE SHOULD BE 50 - 68ff-lbs.