



HOW TO INSTALL RECON E.L. DOOR SILLS

Prior to the installation of your RECON E.L. Door Sills, please follow the instructions below to prevent a short circuit situation in your vehicles electrical system which will cause fuses to blow on your fuse panel.

Mounting:

Mount the door sills directly over-top of the existing door sills using the screws provided in the kit.

Wiring:

The door sills should be wired into the dome light wire on your truck so that the E.L. Door Sills will illuminate when the door is opened and turn off when the door is closed. The dome light wire can be found in numerous locations in the cab of your truck, whether it be in the wire harness running through the kick panel, the fuse box, or the wires running under the door sills. Simply splice the positive wire from our door sill to the dome light wire and ground the negative wire from the EL Door Sill and the install is complete. If you are having any trouble locating the dome light wire in your truck, you can call your local Ford Dealer and they should be able to assist you.

Remarks:

If you install the door sills incorrectly, the E.L. may not function properly and can blow a fuse when tested. In this case simply replace the blown fuse and re-connect the wires in the appropriate way as described above in the instructions.

**If you have any questions, feel free to contact us:
info@reconaccessories.com - www.GoRecon.com**