



# INSTALLATION INSTRUCTIONS

1075 North Ave. Sanger, CA 93657-3539 local: 559-875-0222 fax: 559-876-2259 toll free: 800-445-3767

## 4925 Bump Stop

**Congratulations! You were selective enough to choose a BELLTECH PRODUCT. We have spent many hours developing our line of products so that you will receive maximum performance with minimum difficulty during installation.**

**Note:** Confirm that all of the hardware listed in the parts list is in the kit. **Do not** begin installation if any part is missing. Read the instructions thoroughly before beginning this installation.

**Warning:** **DO NOT** work under a vehicle supported by only a jack. Place support stands securely under the vehicle in the manufacturer’s specified locations unless otherwise instructed.

**Warning:** **DO NOT** drive vehicle until all work has been completed and checked. Torque all hardware to values specified.

**Reminder:** Proper use of safety equipment and eye/face/hand protection is absolutely necessary when using these tools to perform procedures!

**Note:** It is very helpful to have an assistant available during installation.

### RECOMMENDED TOOLS:

- Properly rated floor jack, support stands, and wheel chocks
- Safety Glasses

### KIT INSTALLATION

1. Remove the stock bump stop from the vehicle by pulling it out of the bump stop socket or by using a flat screwdriver to pry it out.
2. Install the new bump stop by pressing it, into the socket.

### PART LIST FOR 4925 Bump Stop Kit

PART#	DESCRIPTION	QTY
4925-001	Bump Stop	2