

73600, 73620 Chrysler/Mitsubishi Rear Camber Kits

Q. The 73600 will not fit in the pocket of the body. What should I do?

A. On some models newer than 2000 the pocket that is used for the rear upper control arm bracket has a flange tab that is in the way when installing the 73600. This extra metal serves no purpose but to get in the way. Just trim of about one-eighth inch so the 73600 bracket will fit flush in the pocket.

Q. What is the difference between the 73600 and the 73620 kits?

A. The only difference between the two kits is the bolt length and the addition of the spacers. The addition of longer bolts and spacers allows for more positive camber change.

Article Information

Hits:

213

Created:

Wednesday, 30 March 2011

Author:

62

Last Modified:

Wednesday, 30 March 2011

Access:

0

Version:

2

Printed from: <http://www.spcalignment.com> On Monday September, 19 2011