



Installation Instructions

Perma Shine Polished Stainless and Black Powder coated Bumpers

Part No. 8449/7649 Front or Rear Double Tube Bumper, 76-06 Jeep® CJ& Wrangler

Parts List:

1-Bumper	2-Rear Mount Brackets L & R	10-10mm Bolts
10-10mm Nuts	18-10mm Flat Washers	10-10mm Lock Washers
8- 12mm Bolts	8-12mm Nuts	16-12mm Flat Washers
8-12mm Lock Washers		

Installation:

Front:

- 1) Remove factory Front bumper and brackets.
- 2) Remove Torx bolts from front Bumper assembly. 2 located on each frame member on top of the Bumper. 1 located underneath on bottom of frame
- 3) Place bumper over frame and locate the holes over existing holes in the frame.
- 4) Replace Torx bolts tighten to 45lbs torque



Rear:

- 1) Remove factory rear bumper
- 2) Locate left and right rear bumper brackets. Place left bracket with large tabs facing outwards, toward the inside centerline of the vehicle. On 76-95 Wranglers/CJ's the holes in the frame will line up. On 96-06 Wranglers the outer holes will be located in the bumper mount frame, the inner holes will need to be drilled. **Warning, drill very carefully through the bumper mount frame as the fuel tank is located directly behind the bumper mount frame.** Attach brackets with 4-10mm bolts, flat washers, lock washers and nuts supplied for each bracket. Tighten to 45lbs torque.
Note: 76-06 Wrangler also will require 10mm bolts through the tab located on the bottom of the brackets into the captured nut in the frame. Tighten to 25Lbs torque



- 3) Locate the rear bumper onto the mounting brackets and attach through the top and bottom of the brackets with 8- 12mm bolts, flat washers, lock washers and nuts supplied. Tighten to 45lbs torque.
- 4) **Warning: It is recommended not to exceed any tongue weight in excess of 200 lbs and 1000 lb gross weight of trailer.**

Rampage Products 9225 Stellar Court, Unit C, Corona, CA 92883
Phone: (951) 277-4949 Fax: (951) 277-2295
e-mail: info@rampageproducts.net
Web: www.rampageproducts.net
Made in China