

# PART NO. 87420

## Instruction Sheet

### GM REAR CAM NUT

*This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.*

1. Remove existing nut from the inboard side of the most forward rear lower control arm.
2. Install the new cam nut making sure it is recessed between the shoulders on the frame bracket.
3. With the bolt slightly loose, adjust toe using the cam nut. Camber may also need to be adjusted.
4. Tighten bolt to manufacturer's specifications.
5. Recheck alignment readings.



**Specialty  
Products  
Company®**

P.O. Box 923 • Longmont, CO 80502 • (303) 772-2103

www.specprod.com • www.spcalignment.com

Email: info@specprod.com

**Toll Free Technical Hot Line: 1-800-525-6505**