

SGG60VS

2008-09 G8 304 Polished Stainless Axle-back w/ Violator Muffler



Pypes Performance Exhaust
2880 Bergey Road Unit O Hatfield, PA 19440
800-421-3890 (voice) 215-712-9968 (fax)
www.pypesexhaust.com

Thanks again for purchasing your new stainless steel Pypes Performance Exhaust 08-09 Pontiac G8 Axle-back system. Please be sure to confirm all the components in the kit were received in your shipment before beginning installation. These kits will include your new Axle-back system w/ Oval polished stainless tips. If you find any components missing, please contact our office at 800-421-3890 for replacement. Installation of these kits will require a few simple tools: jack stands, 13mm & 15mm wrenches and penetrating oil. For a quicker and tighter installation, air tools are recommended. Technical assistance is available both online at www.pypesexhaust.com or 800-421-3890.

Begin by placing the vehicle on a lift or four jack stands at maximum height. This will aid in an easier installation.

1. Unbolt the factory axle-back mufflers from the stock flange using a 13mm wrench. Soaking your factory mounting points with penetrating oil will allow for easier removal. Next, slide the mufflers towards the front of the vehicle to remove them from the factory hangers.

2. It's time to install your new axle-back system. Simply slide the hangers on the new axle-back into the factory mounting point, making sure the gaskets are still in place. Next, bolt the flanges back in place, don't forget the gasket.

Now it's time to fire up that muscle car and enjoy your new Pypes Performance Exhaust.

