



We have our video install guides on our website and on youtube.com Also feel free to call or email us if you have any questions 1-855-457-5683
info@lovethedrive.com

BMW 1 2008 to 2012

Love The Drive Wind Deflector

Install Guide

- * You can raise and lower your convertible top with the wind deflector installed.
- * The wind deflector will fit in the trunk when not in use.

Start by lowering your top and moving the front seats all the way forward.

Your BMW 1 is design to be fitted with a wind deflector. There are two holes on each side of the rear trim panel. The front and rear barrel bolts fit into these holes.



Start by extending both barrel bolts on one end of the wind deflector. Turn the handles so they will face down, when in the car. This locks the bolts into place. These bolts will slide into the holes on the opposite side of the car from which you are standing.



Lower the wind defelctor into the backseat area and insert the front bolt into the hole and then the rear bolt.



Now lower your end into the back seat area so the front barrel bolt is in line with the front hole. Slide the bolt forward into the hole and turn the handle down to lock the bolt.



Next reach back and slide the back bolt into the rear hole and turn the handle down to lock the barrel bolt.



When you are finished please double check to that all four handles are turned downwards so the barrel bolts are in the locked position.



When not in use your wind deflector will store in the trunk. When storing your wind deflector please use the storage bag that is included.



You can now raise the top panel of the wind deflector and you are ready to *Love The Drive.*

