



PLEASE NOTE THAT WE HAVE
INSTALL VIDEOS FOR MANY
MODELS ON GOOGLE VIDEO AND
YOUTUBE.COM. SEARCH UNDER
"WIND DEFLECTOR"

Wind Deflector BMW (E36) 325, 323, M3 1993 to 1999 Installation Guide

**START BY PUTTING YOUR TOP
DOWN AND LEAVING THE LID UP.**

HAVE A FRIEND HELP YOU INSTALL
THE WIND DEFLECTOR THE FIRST
COUPLE OF TIMES. AFTER THAT YOU
WILL BE ABLE TO PUT IT IN AND OUT
BY YOURSELF IN MINUTES.

**STEP 1: MAKE SURE THE BLACK
HOOKS ARE FACING UP**



**STEP 2: PULL OUT THE WIRE
BRACKET OUT FROM THE CLOSED
POSITION**



STEP 3: FROM THE SIDE OF YOUR CAR PLACE THE WIND DEFLECTOR IN THE BACK SEAT AREA OF YOUR CAR

STEP 3 CONT: ALIGN THE BLACK HOOKS, AT THE REAR OF THE WIND DEFLECTOR SO THAT THEY HOOK ON TO THE QUARTER TRIM PANEL. IN THE AREA COVERED BY THE TOP LID



STEP 3 CONT: MAKE SURE BOTH BLACK HOOKS ARE ATTACHED TO THE TRIM PANEL AND THEN CLOSE TOP COVER LID TO HOLD BLACK HOOKS IN PLACE



STEP 4: THE WIRE HOOK ONCE PULLED OUT, WILL REST ON THE TRIM PANEL



STEP 4 CONT: PULL THE WIRE BRACKET BACK AND LOWER TO LINE UP WITH THE HOLE IN THE QUARTER TRIM PANEL



STEP 4 CONT: RELEASE WIRE BRACKET SO IT ENTERS HOLE



STEP 4 CONT: REPEAT ON THE OTHER SIDE AND YOU ARE READY TO GO



**NOW YOU ARE READY TO LOVE THE DRIVE
WWW.LOVETHEDRIVE.COM**