

Toyota Corolla Extender Guide

Installation Guide: Thank you for purchasing The ExtendMySeat brackets. Please follow the directions carefully and within 30 minutes you will be enjoying your much needed legroom.

#### Inventory in Box:

4- ExtendMySeat black brackets4- Black 3/8 x <sup>3</sup>/<sub>4</sub>' stainless grade 8 bolts

#### What you will need for assembly:

- 1- Socket wrench
- 1- Metric 14 socket
- 1- Metric 14 Flat wrench

Step 1- Remove the 2 Black extendmyseat brackets from the packaging and locate the 4 black 3/8" provided bolts.

Step 2- Go to your vehicle with your metric 14 socket and eye protection.

Step 3- Start by loosening and removing the 2 factory bolts in the front seat of the car and move to the rear. Slide your seat all the way forward.



Move to the backseat and remove the 2 plastic guards. Locate and remove the 2 rear factory bolts.

Step 4- Move your seat all the way back. Now lift the front of your seat up so you can slide the brackets under the seat.

Step 5- Lay down the 4 black brackets under the seat so the 4 factory holes lineup (you can choose to remove your seat but it is not necessary) See below picture to identify the 4 part locations.



Step 6- Start by finger tightening the rear factory hole with the factory bolt (closest to the outside of the car) then move to the rear inside and continue in a counter-clockwise pattern. You will finger tighten all of the factory bolts into the factory hole locations. Don't tighten the factory bolts until later.



(rear outside of car location)

Step 7-Line up the factory seat to the new extended hole locations (4" back from the factory holes. Finger tighten the 2 front seat "feet" into the new ExtendMySeat hole locations using the ExtendMySeat bolts.



(View of the front of the seat)

Step 8- Slide the factory seat all the way forward and go the backseat of the car to secure the last 2 remaining ExtendMySeat bolts into the 2 ExtendMySeat holes.



(View from backseat)



(View from backseat)

Step 9- ONCE ALL 8 BOLTS ARE FINGER TIGHT; NOW COMPLETE THE INSTALLATION BY SECURING THE 8 BOLTS TIGHT (4 factory and 4 EMS). CHECK TO MAKE SURE ALL 8 BOLTS ARE NOW TIGHT AND SECURE.

Step 10 - Re-install 2 rear factory plastic guards

Step 11- TEST OUT THE SEAT BY SLIDING THE SEAT BACK AND FORTH. YOU ARE COMPLETE.

To view a video on installation, please visit out YouTube.com channel searching for the channel "ExtendMySeat".

Enjoy

-Griffin