

1998 to Current



Venture

September 25, 2002

2097


| Installation Guide Chevy Venture Van / Pontiac Montana Prod |
|---|
|---|

Extended Wheelbase


| 7. | | | | | | Montana 2121 |
|-----------------------------|---|------|--------------------------|---|------|-----------------------------------|
| | | Qty. | Description | | Oty. | Description |
| Installation Parts List: | A | 1 | GlaStep (Driver Side) | G | 6 | Angled Straps #AS01 |
| | В | 1 | GlaStep (Passenger Side) | H | 24 | 5/16" x 3/4" Washer Head Bolts |
| | C | 4 | Step Pads | I | 24 | 5/16" Washer Head Nuts |
| | D | 2 | Foam Tape Strips | J | 18 | #14 x 3/4" Self-Drilling Screws |
| | E | 6 | Flat Plates #FL44 | K | 6 | #12 x 1-1/4" Self-Drilling Screws |
| | F | 6 | Step Supports #3124F | | | With Rubber Washers |

Tools Required: 5/16" Drill • 1/2" Hex Socket • 1/2" Wrench • 5/16" Nut Driver • 3/8" Nut Driver


- 1. Prior to painting, fit your GlaSteps to the body. A good fit is accomplished when mating surfaces fit with minimum light gaps. Note: Vehicle bodies have variations and a perfect fit may not be possible.
- Painting your GlaSteps. To insure a proper paint finish, use a top quality auto paint system and follow the manufacturers instructions. Your GlaSteps should be sanded and primed before painting.




3. Measure from front wheel well, back 20", 34" and 60". Mark these bracket locations. Note: Steel plates have been inserted under fiberglass to mount brackets securely using self-drilling screws. Double check your marks to be sure they line up with the steel plates before drilling.




4. Assemble bracket components with 5/16" nuts & bolts as shown. Do not tighten at this time.




5. Drill 5/16" hole in pinch weld so that ASO1 on bracket assembly mates at pinch weld. Secure with 5/16" nut and bolt, then install #14 x 3/4" selfdrilling screw at top of FL44.




Apply foam tape to top edge of GlaStep. Remove protective strip from top edge of foam tape.



 Position step on brackets and tight to truck body. Screw step to truck with #12 x 1-1/4" self-drilling screws with rubber washers (K), three per side.



 Screw step to bracket using two #14 x 3/4" self-drilling screws per bracket.
Tighten all bolts to 18 foot pounds.



9. Place pad on step. Peel off tape backing to secure. Don't forget the Owens label!

IN-111 9/25/02