

Installation Guide

Dodge Ram Mega Cab

Product No.

2006 to Current



3105

Note: Drilling into vehicle is required.




	Qty.	Description	Qty.	Description		
Installation Parts List:	A	1	GlaStep #3105-D (Driver Side)	F	8	Angled Straps AS01
	B	1	GlaStep #3105-P (Passenger Side)	G	8	Step Supports #3124F
	C	4	Step Pads 77" x 4"	H	32	5/16" x 3/4" Washer Head Bolts
	D	2	Foam Tape Strips	I	32	5/16" Washer Head Nuts
	E	8	Flat Plates #FL43	J	24	#14 x 3/4" Self-Drilling Screws
			K	6	#12 x 1-1/4" Self-Drilling Screws	

Tools Required: 5/16" Drill • 1/2" Hex Socket • 1/2" Wrench • 5/16" Nut Driver • 3/8" Nut Driver




- Prior to painting, fit your GlaSteps to the body.** A good fit is accomplished when mating surfaces fit with minimum light gaps. Note: Vehicle bodies have variations and a perfect fit may not be possible.
- Painting your GlaSteps.** To insure a proper paint finish, use a top quality auto paint system and follow the manufacturers instructions. Your GlaSteps should be sanded and primed before painting.



- Measure** from front wheel well, back 15", 37", 65" and 83". Mark these bracket locations. Note: Steel plates have been inserted under fiberglass to mount brackets securely using self-drilling screws. **Double check your marks to be sure they line up with the steel plates before drilling.**
- Assemble** bracket components with 5/16" nuts & bolts as shown. **Do not tighten at this time.**



- Drill** 5/16" diameter holes in pinch weld at marks. Bolt brackets FL43 to pinch weld using 5/16" bolts and nuts, then secure to inner rocker panel using #14 x 3/4" self-drilling screws through AS01.
- Apply** foam tape to top edge of GlaStep. Remove protective strip from top edge of foam tape.



- Secure** GlaStep to body with #12 x 1-1/4" self-drilling screws with rubber washers.
- Position** step on brackets and tight to truck body. Screw step to bracket using two #14 x 3/4" self-drilling screws per bracket and adjust GlaStep to body. **Tighten all bolts to 18 foot pounds.**
- Place** pad on step. Peel off tape backing to secure. **Don't forget the Owens label!**

IN302 1/26/06