

Installation Guide

Chevy/GMC Pickup

Product No.

2007

Extended Cab

3152


Installation Parts List:

Qty.	Description	Qty.	Description
A 2	GlaSteps #3152-D/P	F 32	5/16" x 3/4" Washer Head Bolts
B 2	Foam Tape Strips	G 24	5/16" Washer Head Nuts
C 2	Step Pads	H 16	#14 x 3/4" Self-Drilling Screws
D 8	Flat Brackets #FL119	I 8	Clip Nuts
E 8	Step Supports #3124F		


Tools Required:

1/2" Hex Socket • 1/2" Wrench • 5/16" Nut Driver • 3/8" Nut Driver


- Prior to painting, fit your GlaSteps to the body.** A good fit is accomplished when mating surfaces fit with minimum light gaps. Note: Vehicle bodies have variations and a perfect fit may not be possible.
- Painting your GlaSteps.** To insure a proper paint finish, use a top quality auto paint system and follow the manufacturers instructions. Your GlaStep should be sanded and primed before painting.




- Measure** from front wheel well, back 17", 41", 53" and 70". Mark these bracket location centers. Note: Steel plates have been inserted under fiberglass to mount brackets securely using self-drilling screws.




- Remove plastic plug from underbody at all measured locations and install clip nut as shown.




- Assemble FL119 to 3124F using two 5/16" nuts and bolts. **Do not tighten at this time.**




- Attach brackets using 5/16" bolts and nuts through pinch weld holes, and 5/16" bolts into clip nuts.



- Apply foam tape strips to GlaStep edge.



- Secure step support bracket to bottom of GlaStep using two #14 x 3/4" self-drilling screws per bracket. **Tighten all bolts to 18 foot pounds.**



- Place step pad on GlaStep. Peel off tape backing to secure. **Don't forget the Owens label!**

IN317 2/21/07