

Hardware included shown on right.

Tools required:

- 12mm socket
- 3/8" Nut driver
- Drill
- Tape measure

-Painting your Premier board is not necessary nor is it recommended as there is no step tread to protect the painted stepping area. The board is made with UV protected ABS plastic that will resist fading and cracking from the sun.



- 1) Remove factory bolts at 13 ½", 39" and 59 ½" on underside of body. Install CB38 at front location and CB39 at middle and rear locations with previously removed bolts.
- 2) Place board on channel brackets. Center board on vehicle. Attach with #14 X ¾" self-drilling screws through slots in CB brackets into bottom of board.
- 3) **Apply the Owens logo.**
- 4) Repeat steps 1-3 for opposite side.

