

Please read all instructions prior to starting install.

Hardware included shown on right.

Tools required:

- 12mm Metric socket
- 1/2" Standard socket
- Tape measure
- Drill
- 3/8" Nut driver

-Painting your Premier board is not necessary. The board is made with UV protected ABS plastic that will resist fading and cracking from the sun.



Drivers side shown in photos.



Measure from the front wheel well rearward.
At locations 12", 34", 56" and 73 1/2" is where the brackets will be attached. There are factory bolts at these locations, remove but do not discard.



At the 12" location attach one FL113 using the removed factory bolts. Attach one FL114 at the other measured locations using factory bolts.



At the 73 1/2" location only one bolt will be used to attach the FL114.



Insert Square clip nuts into channel brackets as shown.

5)



Attach channel brackets to mounting brackets with 5/16" bolts. Snug but do not tighten.

6)



Place Driver side board on brackets so the board follows the contour of the body then level. Tighten all bolts in brackets and attach the board to the channels with 3/4" long self drilling screws.

7)



Apply step tread by peeling off backer on all tape strips and attach to the stepping area of the board. Apply the logo now also.

8) Repeat steps for passenger side.

