



PLEASE NOTE: WE HAVE A NUMBER OF INSTALL VIDEOS ON OUR WEBSITE, PLEASE LOOK THERE IF SOMETHING IS UNCLEAR.

MERCEDES SL 300, SL500, SL 600 (MB 129) (1990 TO 2002) WIND DEFLECTOR INSTALL GUIDE

YOUR WIND DEFLECTOR ATTACHES TO YOUR ROLL BAR



THERE ARE TWO REAR BRACKETS WITH STRAPS THAT RAP AROUND THE TOP OF YOUR ROLL BAR

THERE ARE ALSO TWO FRONT BRACKETS. THESE BRACKETS ATTACH TO THE TOP OF THE ROLL BAR AND GROOVE ON THE BOTTOM OF THE ROLL BAR



START BY PUTTING YOUR TOP DOWN AND YOUR SEATS FORWARD. RAISE YOUR ROLL BAR UP SO YOU CAN REACH THE STRAPS UNDERNEATH



STAND ON ONE SIDE OF YOUR CAR AND PLACE WIND DEFLECTOR SO THE FRONT BRACKETS SIT UNDER THE GROOVE ON THE BOTTOM OF THE ROLL BAR ON BOTH SIDES



PUSH WIND DEFLECTOR BACK SO THE REAR BRACKETS TOUCH THE ROLL BAR. THE STRAPS RAP AROUND THE ROLL BAR AND ATTACH WITH A BUCKLE. PULL THE STRAPS TIGHT. REPEAT ON OTHER SIDE



LOWER THE ROLL BAR BACK DOWN AND FLIP UP THE TOP PANEL



YOUR WIND DEFLECTOR FOLDS FLAT WHEN THE ROLL BAR IS ENGAGED



YOU ARE NOW READY TO LOVE THE DRIVE

