



PLEASE NOTE THAT WE HAVE A NUMBER OF MODELS WITH INSTALL VIDEOS ON GOOGLE VIDEO. SEARCH UNDER "WIND DEFLECTOR"

# WIND DEFLECTOR

## MERCEDES 300E & E320 (1992 TO 95)

WE HAD TO TURN THE FRONT BRACKETS AROUND SO THE WIND DEFLECTOR WOULD FIT IN THE BOX. YOU WILL NEED A PHILIPS (STAR) SCREW DRIVER TO REMOVE THE SCREWS AND ROTATE THE FRONT BRACKETS 180 DEGREES. THE BOTTOM PHOTO SHOWS THE CORRECT POSITION

YOUR MERCEDES WAS DESIGNED FOR A WIND DEFLECTOR TO FIT JUST BELOW THE REAR SEAT BELT. THERE IS A SPACE FOR THE REAR BRACKET OF THE WIND DEFLECTOR TO SIT ON





STAND BESIDE THE REAR SEAT ON THE OUTSIDE OF THE CAR. START BY INSERTING THE REAR BRACKET IN THE SPACE BELOW THE SEAT BELT ON THE OPPOSITE SIDE TO WHICH YOU ARE STANDING. THEN INSERT THE REAR BRACKET ON THE SIDE CLOSEST TO YOU



THE TWO BRACKETS SHOULD SIT FLAT ON THE TRIM PANEL AND SHOULD NOT INTERFERE WITH THE REAR SEAT BELT



THEN SET THE FRONT OF THE WIND DEFLECTOR DOWN AND THE FRONT BRACKETS WILL REST ON THE SIDE TRIM PANEL



NEXT ATTACH THE TWO STRAPS, TO THE BOTTOM OF THE TRIM PANEL, ONE ON EACH SIDE OF THE FRONT OF THE BACK SEAT



THEN ATTACH THE TWO STRAPS TO THE WIND DEFLECTOR AND PULL THE STRAPS TIGHT



FLIP THE TOP PANEL UP AND YOU ARE READY TO GO. WHEN NOT IN USE THE WIND DEFLECTOR WILL STORE IN THE TRUNK

