



PLEASE NOTE THAT WE HAVE A NUMBER OF INSTALL VIDEOS ON OUR WEBSITE, PLEASE LOOK THERE IF SOMETHING IS UNCLEAR.

## ***MUSTANG 1983 TO 1989 WIND DEFLECTOR INSTALL GUIDE***

**START BY PUTTING YOUR TOP DOWN**

YOUR LOVE THE DRIVE WIND DEFLECTOR FITS IN THE REAR SEAT AREA OF YOUR MUSTANG CONVERTIBLE



THE WIND DEFLECTOR ATTACHES TO YOUR MUSTANG WITH TWO FRONT BRACKETS AND TWO REAR BRACKETS. THE REAR BRACKET IS ADJUSTABLE AND LOCKS THE WIND DEFLECTOR IN PLACE.



STEP 1: THE REAR BRACKETS ARE ADJUSTABLE. START BUT LOSSENING THE THUMB SCREW. PUSH THE BRACKET SO IT IS 3/4 EXTENDED



STEP 2: HAVING PLACED THE PANEL IN THE REAR SEAT AREA. THE FRONT BRACKETS ATTACH TO THE REAR SIDE TRIM PANEL



STEP 3: WITH THE REAR BRACKETS EXTENDED THEY WILL SIT ON TOP OF THE SIDE OF THE REAR TRIM PANEL.



STEP 4: FROM UNDERNEATH THE WIND DEFLECTOR PULL BACK ON THE REAR BRACKET AND THEN TIGHTENED THE THUMB SCREWS HOLD THE WIND DEFLECTOR IN PLACE. REPEAT ON THE OTHER SIDE.



STEP 5: THERE ARE TWO STRAPS THAT ATTACH TO THE BOTTOM OF THE TRIM PANELS. THE BLACK HOOK WILL ATTACH TO THE BOTTOM OF THE TRIM PANEL



THE STRAPS WILL ATTACH TO THE BUCKLES ON THE BOTTOM OF THE WIND DEFLECTOR .

