



We have our video install guides on our website and on youtube.com also feel free to call or email us if you have any questions 1-855-457-5683
info@lovethedrive.com

Mustang with Lightbar 2005 to 2013

Love The Drive Wind Deflector Install Guide

- * You can raise and lower your convertible top with the wind deflector installed.
- * The wind deflector will fit in the trunk when not in use.
- * Start by lowering your top and moving the front seats all the way forward.

Your new Love The Drive wind deflector is shipped to you fully assembled and ready to install. It installs in 30 seconds. It sits in the back seat area and is held in place by four brackets.

The wind deflector stays securely in place using four straps which attach to your cars child seat anchoring system and the side trim panels.



Step 1: Start by lowering the folded wind deflector into the back seat area so the brackets fit onto each side of the trim panel.



Below is a close up to show the two brackets on the trim panel on one side. You may need to adjust the rear brackets to fit tightly against the trim panel



Step 2: Next you need to attach the four straps. The two rear straps with the black snap hooks will clip onto the child seat anchoring system.



On your rear seats there will be a small circle with a child seat picture to show you where the anchors are. The black snap hooks are inserted with the snap facing down. Slide the hook into the hole, press down and then pull back up towards you to secure it into place.



The two front straps will clip onto a hole on the bottom of the side trim panel, below the rear speakers.



Once all four of the straps are connected tighten each strap but not too tight.



Your wind deflector is designed not to touch your light/style bar. It should sit 1/4 of an inch away from your lightbar.