CAPEXi® Exhaust System

Installation Sheet

□Application Vehicle

2		Sion	
2004~2005	Year	tC	Vehicle Name
			Name
	En		
2AZ-FE	Engine Type		
	е		
	Ar	ANT10	Vehicle Code
116-KT06	Apex Product Code	10	Code
)6	Code		

□Parts List

				2	M10×P1.25	Nut	<u>(5)</u>
			9	2	M10×P1.25×L40	Bolt	4
			8	1	P90 φ61	Gasket	ω
1		② Apex Instruction Manual	7	1	Vehicle Specific	Apex Main Muffler Vehicle Specific	2
4	M10	Washer	6	1	Vehicle Specific	Apex Front Muffler Vehicle Specific	Θ
Qty	Size	Part Name	Qty No.	Qty	Size	Part Name	No

□Apex Exhaust System Installation Procedure

- *The diagram only shows partial usage of the nuts and bolts.Please use all of them. . Install the muffler according to the diagram below and hand tighten the nuts and bolts in place.
- 2. Take note of piping clearance, gasket positioning, tip position, chassis clearance clearance and tighten the nuts and bolts into position. Start from the catalytic converter side and work your way back

Torque Specification M10 43~

 $43\sim55N \cdot m + 4.4\sim5.6 \text{ kgf} \cdot m + 31.8\sim40.5 \text{ lb} \cdot \text{ft}$

3.Be sure to confirm tail pipe positioning so that it does not touch the rear bumper. If the positioning unnecessary sound and may melt the bumper.

CAUTION

Be sure to check clearances between brake components, fuel line, and drive train components.

□Checkpoints after Installation

- 3. Test drive the vehicle and check for exhaust leaks or unusual sounds.

2. Rev the engine to 2500rpm to check for any exhaust leaks.

1. After installation, move the exhaust system side to the side by hand to confirm clearances

- 4. If anything usual occurs in steps 1 \sim 3, reinstall the muffler system.
- 5. Retighten all of the nuts and bolts after 200 \sim 300km.

