



We have our video install guides on our website and on youtube.com also feel free to call or email us if you have any questions 604-628-7529 [info@lovethedrive.com](mailto:info@lovethedrive.com)

# PT Cruiser 2005 to 2010

## Love The Drive Wind Deflector

### Install Guide

**Start by putting your top down.**



#### **Step 1:**

Remove the wind deflector from the storage bag and place it in the back seat area.

Start by lining up the plastic slider on the wind deflector with the top of the roll bar. The strap will go under the roll bar.





**Step 2:** The strap will wrap around the roll bar then go through the plastic slider.



**Step 2 Cont:** Pull the strap snug and then fold the strap so the velcro secures it in place.



**Step 2 Cont:** Repeat this process on the other side. You will likely need to make small adjustments to get an even look, with no wrinkles.



**Step 3:** Now attach the wind deflector to the back seat. Using the snap and the black hook that attaches to the side of the trim panel.



**Step 3 Cont:** Make sure the black hook on the elastic is past the edge of the trim panel and hooks to the lip.



**Step 3 Cont:** Repeat on the other side. The elastic and hook will hold the wind deflector in place.





**Step 4:** Push the snap into place (this can take a bit of force) And repeat on the other side.



**Step 5:** The side strap for the wind deflector attaches to the steel bracket on the side of the quarter trim panel.



**Step 5 Cont:** Attach the silver snap hooks to the these steel brackets located behind the front seats.



**Step 5 Cont:** The side strap will hold the wind deflector in place. Repeat on the other side.



**Step 6:** The top of the side straps have a black plastic end clip that will snap onto the end cap on each end of the middle tubes on the wind deflector.



**Step 6 Cont:** These clips will then pull the wind deflector tight. You may need to make a final adjustment of the top straps on the roll bar to smooth out the wrinkles.

