

APPLICATION INSTRUCTIONS

READ CAREFULLY. FOLLOW STEP BY STEP PROCEDURE. BE CAREFUL NOT TO TOUCH OR DIRTY ADHESIVE.

Step 1

Using sandpaper or emery cloth, clean outside diameter of harmonic balancer of all paint and dirt. Wipe clean with a suitable solvent, (such as lacquer thinner). APPLY ONLY TO CLEAN SURFACE.

Step 2

Facing the front of the engine, apply the tape (Steps 3 thru 6) with the numbers reading in a clockwise manner.

Step 3

Leaving short back stripe on tape, start at TDC and peel away back stripe for approximately 1 inch.

Step 4

Align TDC mark on tape with the TDC reference mark on the harmonic balancer. Apply pressure and affix the uncovered portion of the tape.

Step 5

With one hand, continue to remove the long back stripe, while doing so, use the other hand to affix the tape. Continue until entire tape is applied.

Step 6

Remove the short back stripe and press into place, providing an overlapping joint. KEEP IN MIND THAT TAPE MUST BE KEPT ABSOLUTELY CLEAN.

MG 227