



PLEASE NOTE THAT WE HAVE
INSTALL VIDEOS FOR MANY
MODELS ON GOOGLE VIDEO
AND YOUTUBE.COM. SEARCH
UNDER "WIND DEFLECTOR"

Wind Deflector VW CABRIO - MARK 3/4 1994 TO 2004 Installation Guide

START BY PUTTING YOUR TOP DOWN

STEP 1: REMOVE THE WIND DEFLECTOR FROM THE BAG AND PLACE IT IN THE BACK SEAT AREA, IT SITS BEHIND THE FRONT SEATS



STEP 2: START BY LINING UP THE PLASTIC SLIDER UP WITH THE TOP OF THE ROLL BAR. THE STRAP WILL GO UNDER THE ROLL BAR, THEN BACK OVER TOP AND THRU THE PLASTIC SLIDER



STEP 2 CONT: WRAP THE STRAP AROUND THE ROLL BAR THE STRAP THEN GOES THRU THE SLIDER



STEP 2 CONT: PULL THE STRAP SNUG AND THEN FOLD OVER THE STRAP SO THE VELCRO ON EACH SIDE OF THE STRAP IS HELD IN PLACE



STEP 2 CONT: REPEAT ON THE OTHER SIDE. YOU WILL LIKELY NEED TO MAKE SMALL ADJUSTMENTS TO THE STRAP TO GET AN EVEN LOOK, WITH NO WRINKLES



STEP 3: MOVE TO THE BACK OF THE WIND DEFLECTOR. START BY MAKING SURE THAT THE BACK OF WIND DEFLECTOR IS INSIDE THE TRIM PANEL DOWN ABOUT 2 INCHES, INSIDE THE SIDE OF THE BACK SEAT (1/4 TRIM PANEL)



STEP 3 CONT: NEXT PULL THE ELASTIC STRAP IN-BETWEEN THE BACK SEAT AND THE TRIM PANEL.. PULL UNTIL THE VINYL COVERS THE BACK SEAT



STEP 3 CONT: THE ELASTIC WILL FIT SNUGLY BETWEEN THE BACK SEAT AND THE PANEL. REPEAT ON THE OTHER SIDE



STEP 4: MAKE SURE THAT THE VELCRO ON THE BACK OF THE VINYL IS ATTACHED TO THE BACK OF THE BACK SEAT



STEP 5: NEXT ATTACH THE SILVER HOOK TO THE SEATBELT ROD NEAR THE FLOOR. MAKE SURE YOU ATTACH THE HOOK BEHIND THE RUBBER BUMPER SO IT DOES NOT INTERFERE WITH THE SEAT BELT (REPEAT ON THE OTHER SIDE)



STEP 6: NEXT FASTEN THE PLASTIC END SNAPS ON THE STRAP AND ATTACH IT TO THE END OF THE MIDDLE BAR OF THE WIND DEFLECTOR



STEP 6 CONT: ATTACH THE END SNAPS TO EACH OF THE ENDS RODS



THE DOWN STRAP HOLDS THE WIND DEFLECTOR DOWN AND FORWARD



YOU MAY NEED TO ADJUST THE TOP STRAPS ON THE ROLL BAR TO REMOVE SOME OF THE WRINKLES



**NOW YOU ARE READY TO LOVE THE DRIVE
WWW.LOVETHEDRIVE.COM**