
## **FLASH PATTERN** Random Steady Single Mega Double Triple 6 Quad Quint 8 Flash Single-Quad 10 Single H/L Single-Triple-Quint Momentarily apply +VDC to YELLOW wire: · once for next pattern · quickly three times for reset Note: This unit is not factory set at pattern 0





**12 VDC** 

**24 VDC**