



WHIPPLE SUPERCHARGERS MAINTENANCE

WARNING: NEVER MIX SC OIL

AUTOMOTIVE SUPERCHARGER KITS


Its recommended that the following items be inspected at all normal engine service intervals:

1. Check belt condition & tension. Replace or adjust as required.
2. Check the supercharger oil level. Adjust if required.
3. Clean & oil the air filter at the factory recommended intervals.
4. Follow the standard maintenance recommendations by vehicle manufacturer.
5. Change oil as directed below:
 - a. Lysholm compressor ONLY: every 25,000 to 300,000 miles with 5-50 wt. full synthetic motor oil
 - b. New Whipple compressor ONLY: every 75,000 to 100,000 miles with one of the following oils. Whipple part number SCOIL-155 (W140) or SCOIL-200 (W200), Ford Motorcraft part number XL-4, or GM part number 12345982.

WHIPPLE SC OIL LEVEL

Fill to center of oil sight glass. 5.8 fl/oz. or 155cc.

DO NOT OVERFILL, WILL VOID WARRANTY!!



(LYSHOLM UNITS: FILL TO TOP OF KNURLED AREA OF DIPSTICK)