

Scan QR Code with your smart phone for video instructions. Video can also be viewed on our website. See product details.

Installation Instructions JLT Next Generation Cold Air Intake UPGRADE Kit for 1999 & 2001 SVT Cobra #CAI2U-FMC-9901, #CAI2U-FMC-9901-P

Thank you for purchasing our product. We hope you are satisfied with the look and performance. Take your time and it will be a smooth install.

Please review complete instructions prior to installing.

-	
1	Verify you have all of the following parts included in the kit: JLT tube with PVC fitting and IAT grommet, (1) 45° Rubber Throttle Body Elbow, (1) 4.5"-4" Silicone Reducer, (1) Silicone Spacer, (3) #72 Clamps, (1) #64 Clamp Parts being reused from original JLT kit:
	(1) Apron plate, (1) Billet MAF Adaptor with bolts, and (1) 4x6" Air Filter
2	Gather all of the following tools needed for the installation: 5/16 Nut Driver, 10mm Open End Wrench, 11mm Open End Wrench, Phillips Head Screwdriver, Car Jack and Jack Stands
3	Jack the car up using jack stands or drive it on some ramps. Removing the right wheel makes the install much easier, but not totally necessary. Turn wheels all the way to the right.
4	Remove your JLT intake system from the throttle body to the filter housing.
5	Install the silicone spacer & reducer onto the MAF as shown:
	SPACER GOES ON MAF
6	PULL the Inlet Air Temperature sensor from original JLT tube and install in the grommet on bottom side of new JLT tube.
7	Install 45° Rubber elbow and clamps on to the JLT tube. There is a SHORT side on the elbow, be sure to put the SHORT side on the tube (part# should NOT BE SEEN). Insert round end into the hole in the apron plate and rotate it down and on to the throttle body. Tighten the clamp at the throttle body and leave the clamp on the tube loose for final
	adjustment.
	T SIDE

9	Raise the REDUCER/MAF/FILTER assembly up onto the JLT tube. Point MAF top toward the rear of the car and the plug will point toward the driver's fender. By TWISTING the tube at the throttle body you can gain more room right or left. Plug in the MAF and tighten the clamps.
10	Put the splash shield back in and reinstall the push pins and screw.
11	Up top, snug up the clamp at the throttle body and installation is complete. CLAMPS ONLY NEED TO BE LIGHTLY SNUG



This kit includes an S&B Powerstack pre-oiled reusable air filter. The frequency you should clean your filter will depend on your driving conditions. It is recommended to check your filter at every oil change or 3,000 miles. If there is a build up of dirt as thick as the wire mesh, then it's time to clean your filter. As dirt builds up on your filter, the restriction of the airflow also increases. More frequent cleanings will improve your fuel economy and your vehicle's performance.

To properly clean your filter, we recommend the S&B Precision Cleaning & Oiling Kit (located in the 99,01 Cobra Intake section of our website, www.JLTtruecoldair.com).

Thanks for the business. If you have any questions, please e-mail <u>lav@lLTtruecoldair.com</u> or call 757-335-1940. Our hours are Monday-Friday. 8:00am - 5:00pm Eastern Time.

Custom Paint Disclaimer: All custom paint jobs are done by JLT Performance Inc. Every job is different and done by hand. By ordering a custom paint job, you accept this fact and cannot hold JLT Performance liable for the end result not being exactly what you had in your mind. <u>Return Policy</u>: All returns will be subject to a 10%-25% restocking fee. Air Filters will not be accepted for return unless they are in original plastic sealed bag. Please visit <u>www.JLTtruecoldair.com</u> for

complete return policy.

Warranty: JLT Performance Inc. will repair or replace any part of their product found upon our inspection to be defective in workmanship or material within 1 year from the purchase date for the original purchaser.

Disclaimer: JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.