


Installation Instructions For 16784

2003-2008 NISSAN 350Z 3.5L V6



*MAGNAFLOW Performance Exhaust recommends professional installation on all their products

Warning: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

Step 1: (Carefully read all instructions

before installation) Disconnect the vehicle's battery before removal of the OEM exhaust. This will allow the computer to reset itself with the new system, and prevent electrical accidents. To remove the OEM exhaust system, unbolt the connections at the flanges, then disengage the welded hangers from the rubber insulators, and remove muffler and pipes. Do not damage the rubber insulators or discard the OEM fasteners as they will be reused to mount the new system.

Step 2: Install the new resonator assembly at the 2-bolt flanges using the OEM fasteners. Leave all clamps and fasteners loose for final adjustment of the complete system. Install the extention pipe using the supplied flange gasket and fasteners. Install the driver and passenger side muffler assemblies using the supplied clamps and by fitting the welded hangers into the OEM rubber insulators.

Step 3: With all components mounted loosely, adjust the system for overall aesthetics and clearance of frame & bodywork. (MAGNAFLOW recommends at least 1/2" of clearance between the exhaust system and any body panels to prevent heat-related body damage or fire.)

Step 4: Once a final position has been chosen for the new system, evenly tighten all fasteners from front to rear. The supplied band clamps must be VERY tight to properly align the pipes and prevent leaks (Approximately 65ft-lbs). Inspect all fasteners after 25-50 miles of operation and retighten if necessary.