



**Part Number RD1560
Honda Civic Race Division
1999-2000 Si Models**

- 1 Injen Intake
- 1 Injen Filter 2.75" (#1013)
- 1 2.75" Straight Hose
- 2 small Clamps (.040)
- 1 m6 Nut and washer
- 1 Vibra Mount
- 1 10mm Sensor Stub
- 1 1/4" coupler
- 1 13"-10mm
- 1 License Plate Frame
- 1 Instruction

**Note: Parts and accessories are now
available on line at
"injenonline.com"**



**Congratulations! You have just purchased the best engineered,
dyno-proven cold air intake system available.**

Please check the contents of this box immediately.

Report any defective or missing parts to the Authorized Injen Technology dealer you purchased this product from.

Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the dealer you purchased this product from.

Installation DOES require some mechanical skills. A qualified mechanic is always recommended.

*Do not attempt to install the intake system while the engine is hot.





The installation may require removal of radiator fluid line that may be hot.

Injen Technology offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.

Injen Technology 285 Pioneer Place Pomona, CA 91768 USA



Figure 1



Injen Technology now makes oil caps and spark plug covers for this application. Call your local dealer or call Injen technology for details. rd1560

Note: Disconnect the negative battery terminal before starting this installation.

1. Remove the air intake box and air intake duct leading to the throttle body. Remove the air temperature sensor connected to the air intake box.
2. Remove the front bumper and the air resonator box located in the front bumper. (See fig. 7)
3. Place the 2.75" straight hose over the throttle body and use two clamps. Tighten the clamp on the filter at this point. (See fig. 1)
4. Take the vibra-mount and screw it in place. See fig. 4 The intake bracket is sitting on top of the vibra-mount. (See fig. 2)

Warning! The car must be completely cold before removing any lines.

5. Remove the PCV pipe as seen in figure 2. Use the 1/4" coupler to join both lines 1 and 2 together and use the stock clamps to secure the lines. (See fig. 3)
6. Place the cold air intake into the 2.75" hose on the throttle body. Align the intake so that the bracket sits on top of the vibra-mount and use the m6 nut and washer to hold the intake in place. (See figs. 4 and 5)
7. Place the Injen filter in the lower section of the intake and tighten the clamp on the filter. (See fig. 4)
8. Align the entire cold air intake for best fit. Make sure the intake does not rub anywhere along the length of the intake. (See fig. 1)
9. Press one end of the 13"-10mm hose onto the port on the valve cover. The other end will be pressed onto the 1/2" nipple on the intake. (See figs. 5 and 6)
10. Press the 10mm sensor stub into the 3/4" nipple on the intake. Take the air temperature sensor and press it into the 10mm stub placed in the 3/4" nipple. (See figs. 5 and 6)
11. Once the cold air intake has been aligned clearing all exposed lines continue to tighten all nuts, bolts and clamps.
12. Replace the front bumper back to its stock location and reconnect the battery terminal.
13. Remove all tools and rags from the engine compartment before starting the engine. Congratulations! You have just completed the installation.