



July 26, 2006


Installation Guide	Jeep Grand Cherokee	Product No.
2005 to Current		67044

Note: This installation may use some factory bolt hole locations.


		Qty.	Description		Qty.	<u>Description</u>
Installation	A	2	#6613 D/P Running Boards	E	18	5/16" X 3/4" Washer Head Bolts
Danta Liste	В	2	Step Pads 4" x 56"	F	18	5/16" Washer Head Nuts
Parts List:	C	6	Flat Brackets #FL103	G	24	#14 x 3/4" Self-Drilling Screws (short)
	D	6	Step Supports #3124F			

Tools Required: 5/16" Drill • 1/2" Wrench • 1/2" Hex Socket • 5/16" Nut Driver 3/8" Nut Driver


- 1. Prior to painting, fit your Owens Premier Boards to the body. A good fit is accomplished when mating surfaces fit with minimum light gaps. Note: Vehicle bodies have variations and a perfect fit may not be possible.
- 2. Painting your Owens Premier Boards. To insure a proper paint finish, use a top quality auto paint system and follow the manufacturers instructions for painting ABS plastic.




15", 35" and 55". Mark these bracket locations.




3. Measure from front wheel well, back 4. Place flat bracket FL103 against the pinch weld at the locations show above. Drill a 5/16" hole through the pinch weld if factory hole is not there. Mount the flat bracket to the pinch weld with 5/16" nut and bolt. Finish by putting two #14 x 3/4" screws through flat bracket into rocker panel.




5. Use two 5/16" nuts & bolts to secure 3124F step support to FL50. Snug, but do not tighten at this time.



6. Apply foam tape to top edge of running board. Remove protective strip from top edge of foam tape.



7. Center board between wheel wells on brackets attached to vehicle. Screw step to support bracket with two #14 x 3/4" self-drilling screws per bracket. Do not fasten lip of board to vehicle body.



Tighten step support bolt and nut to 18 foot pounds. Place pad on step. Peel off tape backing to secure. Don't forget the Owens label!

IN311 7/26/06