


Hardware included shown on right.

**DRILLING INTO VEHICLE IS REQUIRED!**

Tools required:

- 1/2" socket
- 1/2" wrench
- 5/16" nut driver
- Drill
- 5/16" Drill bit

**-Painting your board is not necessary. The board is made with UV protected plastic that will resist fading and cracking from the sun.**



**NOTE CREW CAB SHOWN IN PHOTOS!**



Measure from front wheel well back and make a mark at :  
 Std Cab— 13" & 38"  
 Ext Cab— 13", 34" & 56"  
 Crew Cab— 13", 31", 49" & 69"



At each of the locations from step one, hold a bracket in place and drill a 5/16" hole through the pinch weld where the bracket will attach.



Attach the bracket with a 5/16" bolt and nut through the bracket and drilled hole. Use one self drilling screw to attach to under body. Tighten all bolts.




Attach 3124F angle support to FL153 flat bracket with 5/16 bolts and nuts. Snug but do not tighten.

5)



For ABS plastic boards, place on brackets and align on truck. Using self drilling screws attach the board to the brackets.

6)



For aluminum boards, insert one square head bolt into track for each bracket.

7)



Place the board on brackets with bolts through slots. Attach with 1/4" nuts.

8)



Level board and tighten all brackets. Repeat all steps for opposite side.