

Hardware included shown on right.

DRILLING INTO VEHICLE IS REQUIRED!

Tools required:

- 1/2" socket
- 1/2" wrench
- 5/16" nut driver
- Drill
- 5/16" Drill bit
- 3/8" nut driver



1)



Remove the plastic edge protector on the front edge of the box. To remove, use a small screw driver to pull out the push pin. Remove and discard.

2)



Locate the holes in the front bed sidewall support.

3)



Attach the FL152 bracket to the sidewall support using 5/16" bolts and nuts.

4)



Apply trimlock to the FL73 brackets as shown.



Locate the bed floor support in front of the rear wheel. This is where the brackets will attach.



Attach FL73 to support with 5/16" bolt and nut. You will need to drill a 5/16" hole through the support for the second bolt.



Attach FL74 to FL73 in the holes shown with 5/16" bolts and nuts.



Attach CH07 brace between the two brackets with 5/16" bolts and nuts.



Attach one 3124F to front bracket and one 3124J to the rear bracket with 5/16" bolts and nuts. Snug but do not tighten.



Apply foam tape to the top lip of the board. Apply step tread and logo now also.

11)



Align the board on the brackets with the cab boards and attach with self drilling screws..

12)



Using the longer self drilling screws with the rubber washer, attach the board to the truck bed through the lip of the bottom lip of the board..

13)



Tighten any and all loose hardware and repeat steps on opposite side.