

Installation Sheet

□Application Vehicle

2003~	Year	Honda Accord 14	Vehicle Name
K24A	Engine Type		
116-KH28	Apex Product Code	CM7	Vehicle Code

□Parts List

_		Apex Instruction Manual	@	_	$P90 \times \phi 61$	Gasket	4
7	M10	Washer	0	1	$PCD86 \times \phi 61$	Gasket	3
5	M10×P1.25	Nut	6	1	Vehicle Specific	Apex Main Muffler	2
2	M10×P1 25×L40	Bolt	⑤	_	Vehicle Specific	Apex Front Muffler Vehicle Specific	Θ
Qty	Size	Part Name	No.	Qty	Size	Part Name	No.

□Apex Exhaust System Installation Procedure

- ≫The diagram only shows partial usage of the nuts and bolts.Please use all of them. 1. Install the muffler according to the diagram below and hand tighten the nuts and bolts in place.
- 2. Take note of piping clearance, gasket positioning, tip position, chassis clearance clearance and tighten the nuts and bolts into position. Start from the catalytic converter side and work your way back

Torque Specification M10 43 \sim 55N·m 4.4 \sim 5.6 kgf·m 31.8 \sim 40.5lb·ft

3.Be sure to confirm tail pipe positioning so that it does not touch the rear bumper. If the positioning unnecessary sound and may melt the bumper.

CAUTION is off, loosen the nuts and bolts and adjust accordingly. Fallure to provide adequate clearance may cause

Be sure to check clearances between brake components, fuel line, and drive train components.

□Checkpoints after Installation

1.After installation, move the exhaust system side to the side by hand to confirm clearances

- 2. Rev the engine to 2500rpm to check for any exhaust leaks
- 3. Test drive the vehicle and check for exhaust leaks or unusual sounds.
- 4. If anything usual occurs in steps $1\sim3$, reinstall the muffler system.
- 5.Retighten all of the nuts and bolts after $200 \sim 300 \text{km}$.

